




REMARK:

- 1 Inlet Isolation Valve
- 2 Membrane Water Filter
- 3 H2O-X2000
- 4 Outlet (spare, disabled) *
- 5 Outlet Isolation Valve
- 6 Timer Controller Isolation Valve
- 7 Timer Controller

* Subject to model

CAUTION!!

- After installation, must rinse filter for at least 5 min. before put into operation.
- User must know how to program the Auto Timer Controller & perform Manual Back-Flush on weekly basis.
- Controller can be installed VERTICALLY ONLY and with at least 150mm clearane distance from ground level.



Piping Connection & Installation Reference Diagram